



PanGu Board

V1.2

PZ1	GND	C1_R	C1_T	GND	PZ3	PZ6	PZ7	GND	ANAO	ANA1	GND	USB+	USB-	GND	5V	5V
P12	P10	P13	GND	PZ5	P11	PZ0	PZ2	PZ4	GND	USB+	USB-	GND	5V	5V		

R187
R186
R185
GND
GND

